



WALK MAKER® BUILDING FORMS

Product Description

QUIKRETE® Walk Maker Building Forms are reusable plastic molds for creating patterned walks, paths, patios, courtyards, etc.

Sizes: QUIKRETE® Walk Maker Building Forms are nominally 2' x 2' x 2"

Patterns: Country Stone, Running Bond Brick, European Block and Basket Weave Brick

INSTALLATION

1. Walk Preparation- The Walk Maker can be placed on any relatively flat surface. It will automatically configure the concrete to the existing base. For professional results, remove one inch of topsoil, and level Walk Maker before filling with concrete. Removed topsoil can be utilized to fill in open spaces on sides and between concrete after walk has set up.

2. Concrete Mixing- Add 2.5 quarts of water to each 80-lb. bag or 2 quarts of water to each 60-lb. bag of QUIKRETE® Concrete or Fiber-Reinforced Concrete Mix. Mix thoroughly until a plastic-like (moldable) consistency is reached. If additional water is required, add small amounts until the correct consistency is obtained. The final water content should be 2.5-4.5 qts. for each 80 lb. bag, or 2-3.5 qts. for each 60 lb. bag.

3. Fill Mold- Use a bucket or trowel to fill each mold cavity level with surface of mold.

4. Smooth Surface- While concrete is still in mold, pat and smooth cavity surface with trowel. Remove mold promptly.



5. Finish Surface- After removing the mold, smooth all edges with a trowel until appearance is satisfactory. Dipping trowel in water may be helpful. Place the mold adjacent to the completed section and continue this process until your project is completed.

6. Curing Concrete and Outlining/Trimming Blocks- Concrete should be damp-cured for 5-7 days for the greatest strength or QUIKRETE® Acrylic Concrete Cure and Seal #8800 can be applied once the concrete hardens, but is still damp. (Apply according to directions on the package). To outline/trim blocks, fill-in separations with QUIKRETE® Sand (Topping) Mix after concrete has cured. Place dry Sand Mix in cracks and sweep in to desired level. Dampen the Sand Mix with a fine mist of water (Do Not Overwet). Let Sand Mix harden to finish the project.

Note: Surface Color and Texture- The addition of QUIKRETE® Liquid Cement Color will dramatically enhance any Walk Maker project. Mix the liquid color with water before adding it to the dry concrete mix. A variety of surface textures may be obtained by experimenting with different finishing techniques; i.e. a metal trowel will make a smooth surface, a wooden trowel will make a rougher surface and a brushed surface will add texture and expose more aggregate.

The QUIKRETE Companies Inc.

One Securities Centre
3490 Piedmont Road, Suite 1300
Atlanta, GA 30305
404.634.9100 • 404.842.1424 Fax • www.quikrete.com