

# QUIKRETE®

## SET POSTS WITHOUT MIXING



### INSTRUCTIONS:

1. Dig a post hole three times the width of the post and a depth equal to 1/3-1/2 of the above ground height, plus 6".
2. Pour 6" of QUIKRETE® All-Purpose Gravel into the bottom of the hole and tamp with a 4x4 post.
3. Place post into hole. Attach angled 2x4 braces to adjacent sides of the post as a temporary support. Then level the post.
4. Fill the hole with Fast-Setting Concrete Mix up to 3"-4" below ground level. Two 50 lb. Bags of QUIKRETE® Fast-Setting Concrete will set a 4" x 4" (or 4" diameter) post in a 10" diameter hole 2 feet deep.
5. Pour water into the dry mix and allow it to soak in. Use enough water to saturate the dry mix.
6. Fill the remainder of the hole with soil dug from the hole. Sets in 20-40 minutes. Wait 4 hours before placing heavy objects.

Refer to package for additional instructions and adverse temperature conditions.

### TOOLS AND MATERIALS NEEDED:

- QUIKRETE® Fast-Setting Concrete
- Post hole digger or power auger
- Pressure-treated wood posts or galvanized steel posts
- Plum line or level
- 2x4 braces
- Nails and hammer
- Gloves
- Safety glasses



**SCAN** *to* **VIEW**

**Set Posts Without  
Mixing  
VIDEO**

or visit [www.quikrete.com](http://www.quikrete.com)

# QUIKRETE®

## COLOCAR POSTES SIN MEZCLAR



### INSTRUCCIONES:

1. Cave un hoyo de tres veces el ancho del poste y a una profundidad igual a 1/3-1/2 de la altura sobre el suelo, más 6".
2. Vierta 6 "de QUIKRETE® All-Purpose Gravel en el fondo del hoyo y apisonese con un poste de 4x4.
3. Coloque el poste en el hoyo. Coloque tirantes de 2x4 en ángulo a los lados adyacentes del poste como un apoyo temporal. Luego nivele el poste.
4. Rellene el hoyo con Fast-Setting Concrete Mix hasta 3"-4" por debajo del nivel del suelo. Dos bolsas de 50 libras de QUIKRETE® Fast-Setting Concrete fijarán un poste de 4" x 4" (o 4" de diámetro) en un hoyo de 10" de diámetro con 60 cm de profundidad.
5. Vierta agua en la mezcla seca y deje que penetre. Utilice suficiente agua para saturar la mezcla seca.
6. Rellene el resto del hoyo con la tierra excavada del mismo. Seca entre 20-40 minutos. Espere 4 horas antes de colocar objetos pesados.

### HERRAMIENTAS Y MATERIALES NECESARIOS:

- QUIKRETE® Fast-Setting Concrete
- Excavador de hoyos para poste o barrenadora
- Postes de madera tratados a presión o postes de acero galvanizado
- Plomada o nivel
- 2x4 tirantes
- Clavos y martillo
- Guantes
- Gafas de seguridad