



When installing a well, the casing must extend above the ground at least 6" (preferably a full foot) in order to keep out groundwater. A concrete well collar placed around the protruding end of the casing provides drainage as well as an effective, watertight seal. Simply

place QUIKRETE® Fast-Setting Concrete Mix in a 2' radius around the casing. Pack the dry mix around the casing and add water. Use a trowel to slope it away from the casing as shown in the illustration.