

Concrete Patching Compound

No. 8650-35

QUIKRETE® Concrete Patching Compound is a ready to use trowel applied acrylic latex formulation for crack and spall repair for concrete, stucco or masonry walls, sidewalks, patios, driveways, etc.

- Dries quickly to a tough and flexible finish
- Helps prevent water and ice damage to concrete surfaces.
- weather resistant
- Excellent Adhesion
- Textured to blend with concrete surfaces
- Easy clean up with water before product dries

Uses: Repairs and fills spalls (surface imperfections) and cracks up to ¹/₄" (6 mm) deep in concrete, masonry, stucco, sidewalks, patios, and driveways.

Packaging: QUIKRETE® Concrete Patching Compound is available in 1 qt. (0.9 L) pails.

Colors: QUIKRETE® Concrete Patching Compound is available in concrete gray or white.

Coverage: QUIKRETE® Concrete Patching Compound will cover approximately 3.25 sq. ft (0.3 M²) at a 1/8" (3 mm) thickness.

Limitations: Apply only when temperature is between 50 degrees F (10 C) and 90 F (32 C). Do not apply if rain threatens or is predicted within 12 hours. Wait at least 24 hours before painting. Use latex paints only. Protect from freezing. Store between

35 F (2 C) and 100 F (38 C). Keep container tightly sealed when not in use.

Application: Surface must be clean, dry, and free of grease, dust, or loose particles. Remove all loose stones and chips from damaged area before filling. Apply to cracks or small spalled areas using a margin trowel. For larger areas use a stainless steel pool trowel or plastic trowel. Use heavy trowel pressure to force the product into the surface. For small areas thicker than ½" (6 mm), apply a 1/8" (3 mm) layer first and allow at least 24 hours before applying a second layer.

Curing: QUIKRETE® Concrete Patching Compound will form a surface skin in 20 – 40 minutes and will become hard in 4 – 6 hours depending on temperature and humidity. Additional curing will continue for about 3 days, longer under low temperature and high humidity conditions.

Clean up: Use soapy water and scrub with a stiff fiber brush before material has dried.

The QUIKRETE® Companies, Inc.